

Cambiar Contraseña Wifi en Huawei HG8245Q2 / HS8546V5



Para cambiar la contraseña wifi en este modelo de router huawei, lo primero que hacemos es dirigimos a nuestro navegador de internet e introducir en la

barra de direcciones la ip de nuestro router, 192.168.100.1

En chrome:

← → ↻ 🌐 192.168.100.1

Buscar con Google

Voy a tener su

Ofrecido por Google en: [català](#) [galego](#) [eus](#)

Una vez que cargue la página del router nos dará una excepción de seguridad por no ser una página https, procederemos de la siguiente:



La conexión no es privada

Es posible que los atacantes estén intentando robar tu información de **10.240.29.64** (por ejemplo, contraseñas, mensajes o tarjetas de crédito). [Más información](#)

NET:ERR_CERT_AUTHORITY_INVALID

Ayuda a mejorar la Navegación Segura enviando [datos del sistema y contenido de las páginas](#) a Google. [Política de Privacidad](#)

Configuración avanzada

Volver para estar a salvo

Pinchamos en configuración avanzada:

Ocultar configuración avanzada

Volver para estar a salvo

Este servidor no ha podido probar que su dominio es **10.240.29.64**, el sistema operativo de tu ordenador no confía en su certificado de seguridad. Este problema puede deberse a una configuración incorrecta o a que un atacante haya interceptado la conexión.

[Acceder a 10.240.29.64 \(sitio no seguro\)](#)

Pinchamos en acceder a x.x.x.x (configuración no segura).

Una vez en la pantalla de login del router introducimos las credenciales:

user
fiberoptic



Pulsamos en login.

Solo podemos ver la clave actual desmarcando **Hide** en **WPA PreSharedKey** si estamos conectados al router por cable, si estamos por Wifi no podremos ver la contraseña.

WIFI 2.4Ghz

1. Seleccionamos la pestaña **WLAN** en el menú superior.
2. Seleccionamos **2.4G Basic Networks Settings** en la barra lateral izquierda.
3. En **WPA PreSharedKey** escribimos la nueva contraseña.
4. Guardamos con **Apply**.

On this page, you can set the basic parameters of 2.4 GHz wireless network(When the 2.4 GHz wireless network is disabled, this page is blank).

Caution:

1. Wireless network services may be interrupted temporarily after you modify wireless network parameters.
2. It is recommended that you use the WPA2 or WPA/WPA2 authentication mode for security purposes.

Enable WLAN New Delete

SSID Index	SSID Name	SSID Status	Number of Associated Devices	Broadcast SSID	Security Configuration
1	VozplusFibraCHF3316-24Ghz	Enabled	32	Enabled	Configured

SSID Configuration Details

SSID Name: * (1-32 characters)

Enable SSID:

Number of Associated Devices: * (1-32)

Broadcast SSID:

Enable WMM:

Authentication Mode:

Encryption Mode:

WPA PreSharedKey: Hide * (8-63 characters or 64 hexadecimal characters)

WPA Group Key Regeneration Interval: *(600-86400s)

Enable WPS:

WPS Mode:

PBC:

Copyright © Huawei Technologies Co., Ltd. 2008-2018. All rights reserved.

WIFI 5Ghz

1. Seleccionamos la pestaña **WLAN** en el menú superior.
2. Seleccionamos **5G Basic Network Settings** en la barra lateral izquierda.
3. En **WPA PreSharedKey** escribimos la nueva contraseña.
4. Guardamos con **Apply**.

HUAWEI HG8245Q2 Logout

Status WAN LAN IPv6 **WLAN** Security Forward Rules Network Application System Tools Bundle

2.4G Basic Network Settings WLAN > 5G Basic Network Settings

2.4G Advanced Network Settings

5G Basic Network Settings

5G Advanced Network Settings

Automatic WiFi Shutdown

WiFi Coverage Management

On this page, you can set the basic parameters of 5 GHz wireless network(When the 5 GHz wireless network is disabled, this page is blank).

Caution:

1. Wireless network services may be interrupted temporarily after you modify wireless network parameters.
2. It is recommended that you use the WPA2 or WPA/WPA2 authentication mode for security purposes.

Enable WLAN New Delete

SSID Index	SSID Name	SSID Status	Number of Associated Devices	Broadcast SSID	Security Configuration
<input type="checkbox"/> 5	VozplusFibraCHF3316-5GHzEnabled	32	Enabled	Configured	

SSID Configuration Details

SSID Name: * (1-32 characters)

Enable SSID:

Number of Associated Devices: * (1-32)

Broadcast SSID:

Enable WMM:

Authentication Mode:

Encryption Mode:

WPA PreSharedKey: Hide * (8-63 characters or 64 hexadecimal characters)

WPA Group Key Regeneration Interval: *(600-86400s)

Enable WPS:

WPS Mode:

AP-PIN:

Copyright © Huawei Technologies Co., Ltd. 2008-2018. All rights reserved.

clientes/routers/wifi-pass-hg8245q2.txt · Última modificación: 07/10/2020 10:30 por jose